
Lyurs Flooring Maintenance Guide

Your Lyrus waterproof flooring is finished with an ultra durable acrylic coating that when maintained and protected properly, will provide a timeless beautiful floor to your space for many years.

Getting Started- Non rubber-backed, flooring safe rugs, should be used at entry ways, Felt pads should be installed under all chair legs or furniture that slide directly on the flooring. Rolling chairs should always have a glass or plastic protection pad underneath them. Rolling chairs without floor protection can cause the locking system used on Lyrus flooring to fail. Always lift and move heavy items or furniture. Never slide furniture as it can dent or scratch the flooring. Maintain indoor temperature between 65 and 85 degrees. South and West facing windows should have window coverings installed and used during the afternoon.





Basic Cleaning- For everyday cleaning and maintenance use a basic bristle broom or vacuum that doesn't use an abrasive beater bar. To spot clean, use a damp microfiber cloth.

Deeper Cleaning- For the majority of spills and deep cleaning only plain clean water is required. For harder stains or spills we recommend Ph neutral floor cleaner. If a non Ph neutral cleaner is used it will leave residue that attracts dust and can be impossible to remove. Lyrus flooring should only be cleaned with a damp microfiber replaceable head style mop as pictured. Never use a traditional wet mop. For larger areas clean out or replace microfiber once it becomes dirty with clean water. For Lyurs Flex glue-down flooring a steam mop should never be used. It can force moisture under the flooring and cause the adhesive to fail.

